



Crown position		
Crown position		
	0 click	1st click
Crown	Clockwise : Manual winding CounterClockwise : Free	Time setting / Second hand stop