

— MODE
(B KEY)

— SET
(A KEY)


A. Features

- 3.5 Digits LCD Display, Display Hour, Minute (Month and Day, Second)

B. Operational Manual

- At time setting mode, press B key to activate auto advance function.
- Press B key once displaying Date; twice displaying Second, Press B key again to return to Real Time mode .
- Time Setting

• Press A key twice to entry Time Setting mode, select item in turn as following:



- Press B key to adjust the flashing item.
- Press A key to confirm.